

TECOM AH4021

CLI Reference Manual

Version 3.00L.01V.01

Table of Contents

[CLI Command List](#)3

[Table - Effect of AH4021 Commands](#)4

[Control Key Support](#)5

[ADSL](#)6

[ARP](#)11

[ATM](#)12

[BRCTL](#)16

[CAT](#)18

[DDNS](#)19

[DEFAULTGATEWAY](#)20

[DF](#)21

[DHCPSEVER](#)22

[DNSRELAY](#)24

[DUMPCFG](#)26

[ECHO](#)28

[HELP](#)29

[IFCONFIG](#)30

[KILL](#)32

[LAN](#)33

[LOGOUT](#)35

[PASSWD](#)36

[PING](#)37

[PPP](#)38

[PS](#)39

[PWD](#)40

[REBOOT](#)41

[REMOTEACCESS](#)42

[RESTOREDEFAULT](#)43

[ROUTE](#)44

[SAVE](#)46

[SNTP](#)47

[SWVERSION](#)48

[SYSINFO](#)49

[TFTP](#)50

[VOICE](#)51

[WAN](#)53

[WLCTL](#)58

CLI Command List

The following commands are available from AH4021 command line interfaces.

- From Linux busybox:
 - cat
 - df
 - dumpmem (hidden command)
 - echo
 - ifconfig
 - kill
 - ping
 - ps
 - pwd
 - reboot
 - setmem (hidden command)
 - sh (hidden command)
 - logread (hidden command and only if syslog is enabled)
 - sysinfo
 - tftp

- From Linux public domain
 - brctl
 - eatables (hidden command)
 - iptables (hidden command)

- From AH4021:
 - adsl
 - atm
 - arp
 - cat
 - defaultgateway
 - dhcpserver
 - dnsrelay
 - dumcfg
 - help
 - lan
 - logout
 - passwd
 - ppp
 - pwd
 - remoteaccess
 - restoredefault
 - route
 - save
 - swversion
 - voice
 - wan
 - wlctl

Table - Effect of AH4021 Commands

Command	Effective at runtime	Save to CFM runtime database	Save to flash config file	Comments
adsl	Yes	Yes	Yes	
atm	Yes	Yes	Yes	
arp	Yes	No	No	
cat	Yes	No	No	
defaultgateway	Yes	Yes	Yes	If command contains interface as option then this interface must already exist. WAN and LAN interface configuration requires reboot to be brought up.
dhcpserver	No	Yes	Yes	
dnsrelay	See comments	Yes	Yes	If change from dynamic to static then effective at run time, but if change from static to dynamic then effect after system is rebooted.
dumcfg	Yes	No	No	
help	Yes	No	No	
lan	No	Yes	Yes	
logout	Yes	No	No	
passwd	Yes	Yes	Yes	Effect after logout
ppp	Yes	No	No	
pwd	Yes	No	No	
remoteaccess	Yes	Yes	Yes	
restoredefault	See comments	Yes	Yes	Effect after system is rebooted automatically
route	Yes	Yes	Yes	If command contains interface as option then this interface must already exist. WAN and LAN interface configuration requires reboot to be brought up.
save	Yes	No	Yes	
swversion	Yes	No	No	
voice	Yes	Yes	Yes	
wan	No	Yes	Yes	
wlctl	Yes	No	No	Use WEB UI to save to flash or CFM database.

Control Key Support

1. Command history scrolling (maximum 15 commands in history)
 - UP: UP arrow key, or CTL+p
 - DOWN: DOWN arrow key, or CTL+n

2. Move cursor
 - a. LEFT: LEFT arrow key, or CTL-b
 - b. RIGHT: RIGHT arrow key, or CTL-f
 - c. Beginning of line: CTL+a
 - d. End of line: CTL+e

3. Clear screen: CTL+l (lowercase letter of L)

4. Clear to the beginning of line: CTL+u

5. Clear to the end of line: CTL+k

6. Delete: DEL key, or CTL+h

7. Terminate: CTL-c (can not terminate certain running application such as ping)

ADSL

NAME

adsl -- allow a user to control the AH4021 ADSL driver

SYNOPSIS

```
adsl start [options]
adsl stop
adsl connection [options]
adsl configure [options]
adsl bert [options]
adsl info [options]
```

DESCRIPTION

Adsl is used to control the ADSL driver. This utility can:

- start and stop the driver
- activate, deactivate and control ADSL connection
- configure ADSL driver and connection parameters
- start, stop and monitor Bit Error Rate Test (BERT)
- display status and information of ADSL driver and connection
- display statistics for ADSL driver and connection

All information is displayed to stdout. A program or shell script that calls this utility can redirect stdout to a file and then parse the file in order to interpret the displayed output.

COMMANDS

start

Starts the Broadcom ADSL driver. This command initializes the driver and starts ADSL PHY connection if [--up] is specified. This command takes parameters that can specify various connection modes. These parameters are the same as in "configure" command.

stop

Stops ADSL connection and ADSL driver.

configure

Configures ADSL connection parameters. This command takes the same parameters as "start" command except for [--up]. This command will cause ADSL PHY to retrain.

connection

Controls ADSL connection modes, such as up and down and several special test modes. This command can also be used to specify tone selection for upstream and downstream.

bert

Controls ADSL bit error rate test (BERT). This command can start/stop the BERT test and monitor its results.

info

Display information about ADSL driver and PHY status.

OPTIONS

Options for the start and configure commands

```
adsl start [--up] [--mod <a|d|l|t|2|p|e|m>] [--lpair <(i)nner|(o)uter>]
  [--trellis <on|off>] [--snr <snrQ4>] [--bitswap <on|off>]
```

or for AnnexC:

```
  [--bm <(D)BM|(F)BM>] [--ccw]
```

```
adsl configure [--mod <a|d|l|t|2|p|e|m>] [--lpair <(i)nner|(o)uter>]
  [--trellis <on|off>] [--snr <snrQ4>] [--bitswap <on|off>]
```

or for AnnexC:

```
  [--bm <(D)BM|(F)BM>] [--ccw]
```

--up

Will call BcmAdsl_ConnectionStart to start ADSL PHY connection

```
--mod <a|d|l|t|2|p|e|m>
a - all modulations allowed.
d - G.DMT enabled
l - G.Lite enabled
t - T1.413 enabled
2 - ADSL2 (G.992.3) enabled
p - ADSL2+ (G.992.5) enabled
e - Reach extended ADSL (AnnexL) enabled
m - Double upstream (Annex M) enabled
```

More than one mode letter can be given to enable several modes.

```
--lpair <(i)nner|(o)uter>
(i)nner -inner loop pair is used
(o)uter - outer loop pair is used
```

```
--trellis <on|off>
Enabled or disables trellis coding
```

```
--snr <snrQ4>
Specify SNR margin as Q4 number
```

```
--bitswap <on|off>
Enables or disables ADSL bitswap
```

The following options apply to AnnexC only

```
--bm <(D)BM|(F)BM>
(D)BM - DBM mode
(F)BM - FBM mode
```

```
--ccw
Enables special CRC workaround for Centillium modems
```

Options for the stop command

```
adsl stop
```

Options for the connection command

```
adsl connection [--up] [--down] [--loopback] [--reverb]
[--medley] [--noretrain] [--L3]
[--tones <xmtStart xmtNum xmtMap rcvStart rcvNum rcvMap>]
```

```
--up
Starts ADSL connection in normal mode
```

```
--down
Puts ADSL PHY in idle mode
```

```
--loopback
Puts ADSL PHY in ATM cell loopback mode. In this modem ADSL PHY will not
try to establish connection
```

```
--reverb
Puts ADSL PHY in test mode in which it only sends REVERB signal
```

```
--medley
Puts ADSL PHY in test mode in which it only sends MEDLEY signal
```

```
--noretrain
In this mode ADSL PHY will be trying to establish connection as in normal
mode, but once the connection is up it will not retrain even if the
signal is lost.
```

```
--L3
Puts ADSL modem in L3 power state
```

```
--tones <xmtStart xmtNum xmtMap rcvStart rcvNum rcvMap>
Specifies tones which can be used by ADSL PHY.
xmtStart - first tone used in upstream direction (usually 0)
xmtNum - number of tones in upstream direction (usually 32)
xmtMap - bitmap for tones used in upstream direction. Specified as a
hexadecimal string. Bit value zero means the corresponding
tone is not used, bit value one means it is used.
rcvStart - first tone used in downstream direction (usually 32)
rcvNum - number of tones in downstream direction (usually 224)
```

rcvMap - bitmap for tones used in downstream direction. Specified as a hexadecimal string. Bit value zero means the corresponding tone is not used, bit value one means it is used.

Tone configuration command does not cause ADSL PHY retrain Automatically. To experience the effect of this command ADSL connection must be restarted using for example adsl connection -down followed by adsl connection -up command.

Tone selection is not affected by adsl configure commands and has to be changed explicitly. Default tone configuration (all tones enabled) will be set by adsl tones 0 32 0xFFFFFFFF 32 224 0xFF... (repeated 28 times)

Options for the bert command

adsl bert [--start <seconds>] [--stop] [--show]

--start

Starts Bit Error Rate Test (BERT)
seconds - duration of BERT test in seconds

--stop

Stops the BERT test.

--show

Display BERT results to stdout in the following format:

```
BERT Status = [NOT] RUNNING
BERT Total Time = 10 sec
BERT Elapsed Time = 10 sec
BERT Bits Tested = 0x000000000045A6380 bits
BERT Err Bits = 0x00000000000000002 bits
```

BERT Status indicates whether or not the BERT test is currently running. It can be used to monitor when the BERT test is complete after it is started. The numbers of total bit tested and errorred bits are displayed as 64 bit hexadecimal numbers.

Options for the info command

adsl info [--state] [--show] [--stats] [--SNR] [--reset]

--state

Displays the shortest message about ADSL PHY connection state, e.g.
adsl: ADSL driver and PHY status
Status: Showtime Channel: FAST, Upstream rate = 8064 Kbps, Downstream rate = 1024 Kbps

--show

Displays more statistics about ADSL connection.

--stats

Displays all available statistics about ADSL connection.

--SNR

Displays signal to noise ratio (SNR) per tone

--reset

Clears all statistic counters in ADSL driver

EXIT CODES

Exit codes less than 100 are assigned by the ADSL driver. Exit codes of 100 or greater are assigned by the adsl utility.

```
BCMADSL_STATUS_SUCCESS 0
BCMADSL_STATUS_ERROR 1
ADSL_GENERAL_ERROR 100
ADSL_ALLOC_ERROR 101
ADSL_INVALID_COMMAND 102
ADSL_INVALID_OPTION 103
ADSL_INVALID_PARAMETER 104
ADSL_INVALID_NUMBER_OF_OPTIONS 105
ADSL_INVALID_NUMBER_OF_PARAMETERS 106
```


EXAMPLES

- A simple initialization.

```
adsl start [--up]
```

or

```
adsl start
adsl connection --up
```

- A more complex initialization.

```
adsl start --up --mod dl --lpair I
```

or

```
adsl start
adsl connection --up --mod dl --lpair I
```

- Getting in and out of the test modes

```
adsl connection --reverb
```

...

```
adsl connection --up
```

- Selecting tones

```
adsl connection --tones 0 32 0xFEFFFFFF7F 32 224 0xFEFFFFFFF7F
```

selects tones from 1 to 31 for upstream and from 33 to 95 for downstream

- Starting and monitoring BERT

```
adsl bert -start 60
```

to run BERT test for 60 seconds. After about 20 seconds of BERT running the results will look like:

```
adsl bert -show
```

```
adsl: BERT results:
BERT Status = RUNNING
BERT Total Time = 60 sec
BERT Elapsed Time = 20 sec
BERT Bits Tested = 0x0000000008B4C700 bits
BERT Err Bits = 0x0000000000000067 bits
```

After 60 seconds when the BERT has completed the results of -show command will be:

```
adsl bert -show
```

```
adsl: BERT results:
BERT Status = NOT RUNNING
BERT Total Time = 60 sec
BERT Elapsed Time = 60 sec
BERT Bits Tested = 0x000000001A1E5500 bits
BERT Err Bits = 0x0000000000000067 bits
```

- Display minimal ADSL state.

```
adsl info --state
```

```
adsl: ADSL driver and PHY status
Status: Showtime Channel: FAST, Upstream rate = 8064 Kbps, Downstream rate = 1024 Kbps
```

- Display complete ADSL driver and PHY status.

```
adsl info --show
```

```
adsl: ADSL driver and PHY status
Status: Showtime Channel: FAST, Upstream rate = 8064 Kbps, Downstream rate = 1024
Kbps
Mode: G.DMT
Channel: Fast
Trellis: ON
Line Status: No Defect
Training Status: Showtime
Down Up

SNR (dB): 16.1 7.0
Attn(dB): 0.0 5.5
Pwr(dBm): 6.5 7.8
Max(Kbps): 11040 1088
Rate (Kbps): 0 0
K: 0(0) 0
R: 0 0
S: 1 1
D: 1 1
SF: 25288 25286
SFErr: 1 0
RS: 0 0
RSCorr: 0 0
RSUnCorr: 0 0
HEC: 1 0
OCD: 0 0
LCD: 0 0
ES: 1 0
```

ARP

NAME

arp - manipulate modem's ARP (Address Resolution Protocol) table

SYNOPSIS

```
arp add <IP address> <MAC address>
arp delete <IP address>
arp show
arp --help
```

DESCRIPTION

arp is used to manipulate modem's ARP table. Note that ARP entries added by this command are not saved in the flash memory by the save command. After system reboot, ARP entries need to be re-added.

EXAMPLES

- Add a static ARP entry for IP address 192.168.1.2 with MAC address 00:11:22:33:44:55.

```
>arp add 192.168.1.2 00:11:22:33:44:55
```

- Show ARP table.

```
> arp show
```

```
IP address  HW type  Flags HW address      Mask  Device
192.168.1.3  0x1     0x2   00:01:03:E3:4F:F9  *    br0
192.168.1.2  0x1     0x6   00:11:22:33:44:55  *    br0
```

- Delete ARP entry for IP address 192.168.1.2.

```
>arp delete 192.168.1.2
```

ATM

NAME

atm - allow a user to control the Broadcom BCM63xx ATM driver

SYNOPSIS

```
atm start [options]
atm stop
atm operate tdte|intf|vcc [options]
```

DESCRIPTION

Atm is used to control the ATM driver. This utility can:

- start and stop the driver
- activate and deactivate an ATM interface (port) or a Virtual Channel Connection (VCC)
- add and remove traffic descriptor table entries
- add and remove VCCs
- display the configuration for traffic descriptor table entries, ATM interfaces and VCCs
- display statistics for ATM interfaces and VCCs

All information is displayed to stdout. A program or shell script that calls this utility can redirect stdout to a file and then parse the file in order to interpret the displayed output.

COMMANDS

```
start
    Starts the ATM driver. This command initializes the driver and adds one
    UBR traffic descriptor table entry.

stop
    Stops the ATM driver.

operate
    Operates on traffic descriptor table entries, ATM interfaces and VCCs.
```

OPTIONS

Options for the start command

```
atm start [--cqs <size>] [--pqs <size>] [--bs <size>] [--bo <offset>]
    [--intf <port> <type> <address>]
```

```
--cqs <size>
    size - Size used to create the Free and Receive cell queues. Default
    value is 10.

--pqs <size>
    size - Size used to create the Free and Receive packet queues. Default
    value is 200.

--bs <size>
    size - Size of a buffer used in the Free and Receive packet queues.
    Default value is 1600.

--bo <offset>
    offset - Offset into a receive buffer where data is to be received.
    Default value is 32.

--intf <port> <type> <address>
    port - Port number starting at 0 to be configured.
    type - adsl|loopback|utopia|tc
    address - UTOPIA address. Only used if type is utopia.
```

More than one intf option can be specified to configure multiple ports. If no intf option is specified, the default value is "0, adsl, 0".

Options for the stop command

```
atm stop
```

Options for the operate tdte command

```
atm operate tdte [--add <type> [<pcr>] [<scr>] [<mbs>]] [--delete <index>]
    [--show [<index>]]

--add <type> [<pcr>] [<scr>] [<mbs>]
    type - ubr|ubr_pcr|cbr|rtvbr|nrtvbr
    pcr - Peak Cell Rate (PCR) if type requires it
    scr - Sustainable Cell Rate (SCR) if type requires it
    mbs - Maximum Burst Size (MBS) if type requires it
--delete <index>
    index - Traffic descriptor table entry index to delete. The show option
    displays the current index values.
--show [<index>]
    index - Traffic descriptor table entry index to display information about.

    If index is omitted, all traffic descriptor table entries are displayed.
```

Options for the operate intf command

```
atm operate intf [--state <port> <type>] [--show [<port>]]
    [--stats [<port>] [reset]]

--state <port> <type>
    port - Port number starting at 0 to enable or disable.
    type - enable|disable
--show [<port>]
    port - Port number starting at 0 to display configuration information
    about.
    If port is omitted, configuration information is displayed for all
    configured ports.
--stats [<port>] [reset]
    port - Port number starting at 0 to display statistics for.
    reset - Resets statistics fields.
    If port is omitted, statistics are displayed for all configured ports.
```

Options for the operate vcc command

```
atm operate vcc [--add <port.vpi.vci> <aal_type> <tdte_index>
    <encapsulation_type>] [--delete <port.vpi.vci>] [--addq <port.vpi.vci>
    <size> <priority> ] [--deleteq <port.vpi.vci> <size> <priority>]
    [-- state <port.vpi.vci> <type>] [--show [<port.vpi.vci>]]
    [--stats [<port.vpi.vci>] [reset]]

--add <port.vpi.vci> <type> <tdte_index> <encapsulation_type>
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to add.
    type - aal5|aal2|aal0pkt|aal0cell|aaltransparent
    tdte_index - Traffic descriptor table entry index to use for this VCC.
    The command, atm operate tdte --show, displays the current index
    values.
    encapsulation_type -
        vcmux_routed|vcmux_bridged8023|llcencaps|other|unknown
--delete <port.vpi.vci>
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to delete.

--addq <port.vpi.vci> <size> <priority>
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to add a
    new queue for.
    size - Size of the queue.
    priority - Priority of the queue.
--deleteq <port.vpi.vci> <size> <priority>
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to delete
    a queue for.
    size - Size of the queue.
    priority - Priority of the queue.
```

```

--state <port.vpi.vci> <type>
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to enable
    or disable.
    type - enable|disable
--show [<port.vpi.vci>]
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to
    display configuration information about.
    If port.vpi.vci is omitted, configuration information is displayed for
    all configured VCCs.
--stats [<port.vpi.vci>] [reset]
    port.vpi.vci - Port number, VPI and VCI that identifies the VCC to
    display statistics for.
    reset - Resets statistics fields.
    If port.vpi.vci is omitted, statistics are displayed for all configured
    VCCs.

```

EXIT CODES

Exit codes less than 100 are assigned by the ATM driver. Exit codes of 100 or greater are assigned by the atm utility.

```

ATMDRV_SUCCESS 0
ATMDRV_ERROR 1
ATMDRV_STATE_ERROR 2
ATMDRV_PARAMETER_ERROR 3
ATMDRV_ALLOC_ERROR 4
ATMDRV_RESOURCE_ERROR 5
ATMDRV_IN_USE 6

ATMDRV_VCC_DOWN 7
ATMDRV_INTERFACE_DOWN 8
ATMDRV_LINK_DOWN 9
ATMDRV_NOT_FOUND 10
ATMDRV_NOT_SUPPORTED 11
ATM_GENERAL_ERROR 100
ATM_ALLOC_ERROR 101
ATM_INVALID_COMMAND 102
ATM_INVALID_OPTION 103
ATM_INVALID_PARAMETER 104
ATM_INVALID_NUMBER_OF_OPTIONS 105
ATM_INVALID_NUMBER_OF_PARAMETERS 106

```

EXAMPLES

- A simple initialization.


```

atm start
atm operate vcc --add 0.0.35 aal5 1 vcmux_bridged8023

```
- A more complex initialization.


```

atm start --pqs 400 --bo 0
atm operate tdte --add ubr_pcr 15000
atm operate tdte --show

index type pcr scr mbs
1 ubr 0 0 0
2 ubr_pcr 15000 0 0

atm operate vcc --add 0.0.35 aal5 2 vcmux_bridged8023

```
- Display interface configuration (assumes that the ATM driver is started).


```

atm operate intf --show

port status type
0 enabled adsl

```

- Create and display a VCC configuration (assumes that the ATM driver is started).

```
atm operate vcc --add 0.0.35 aal5 1 vcmux_bridged8023 --addq 0.0.35 64 2
--addq 0.0.35 80 1
atm operate vcc --add 0.0.36 aal5 1 vcmux_routed --addq 0.0.36 128 1
atm operate vcc --show
```

vcc	status	type	tdte_index	q_size	q_priority	encapsulation
0.0.35	enabled	aal5	1	64	2	vcmux_bridged8023
				80	1	
0.0.36	enabled	aal5	1	128	1	llcencaps

- Display interface statistics (assumes that the ATM driver is started).

```
atm operate intf --stats
```

```
interface statistics for port 0
in octets 8130336
out octets 46512
in errors 0
in unknown 0
in hec errors 0
in invalid vpi vci errors 0
in port not enable errors 0
in pti errors 0
in circuit type errors 0
in oam rm crc errors 0
in gfc errors 0
```

```
aal5 interface statistics for port 0
in octets 8130336
out octets 46512
in ucast pkts 5426
out ucast pkts 189
in errors 0
out errors 0
in discards 0
out discards 0
```

- Display VCC statistics (assumes that the ATM driver is started and two VCCs are configured).

```
atm operate vcc --stats
```

```
aal5 vcc statistics for 0.0.35
crc errors 0
oversized sdus 0
short packet errors 0
length errors 0
```

```
aal5 vcc statistics for 0.0.36
crc errors 0
oversized sdus 0
short packet errors 0
length errors 0
```

BRCTL

NAME

brctl - bridge administration utility

SYNOPSIS

brctl [command]

DESCRIPTION

brctl is used to set up, maintain, and inspect the bridge configuration.

A bridge is a device commonly used to connect different networks (Ethernet, USB, 802.11x wireless network or ATM) together, so that these networks will appear as one network to the participants.

Each of the networks being connected corresponds to one physical interface (port) in the bridge. These individual networks are bundled into one bigger ('logical') network, this bigger network corresponds to the bridge network interface such as "br0".

COMMANDS

addbr <bridge>
Creates a new instance of the bridge. The network interface corresponding to the bridge will be called <bridge>.

delbr <bridge>
Deletes the instance <bridge> of the bridge. The network interface corresponding to the bridge must be down before it can be deleted.

show <bridge>
Shows the instance <bridge> of the bridge.

show
Shows all current instances of the bridge.

addif <bridge> <device>
Makes the interface <device> a port of the bridge <bridge>. This means that all frames received on <device> will be processed as if destined for the bridge. Also, when sending frames on <bridge>, <device> will be considered as a potential output interface.

delif <bridge> <device>
Detaches the interface <device> from the bridge <bridge>.

showmacs <bridge>
Shows a list of learned MAC addresses for this bridge.

showstp <bridge>
Shows the STP (Spanning Tree Protocol) status of this bridge.

setageing <bridge> <time>
Sets the MAC address ageing time, in seconds. After <time> seconds of not having seen a frame coming from a certain address, the bridge will time out (delete) that address from the Forwarding DataBase (fdb).

setbridgeprio <bridge> <priority>
Sets the bridge's priority to <priority>. The priority value is an unsigned 16-bit quantity (a number between 0 and 65535), and has no dimension. Lower priority values are 'better'. The bridge with the lowest priority will be elected 'root bridge'.

setfd <bridge> <time>
Sets the bridge's 'bridge forward delay' to <time> seconds.

setgcint <bridge> <time>
Sets the garbage collection interval for the bridge <bridge> to <time> seconds. This means that the bridge will check the forwarding database for timed out entries every <time> seconds.

sethello <bridge> <time>
Sets the bridge's 'bridge hello time' to <time> seconds.

setmaxage <bridge> <time>
Sets the bridge's 'maximum message age' to <time> seconds.

setpathcost <bridge> <port> <cost>

Sets the port cost of the port <port> to <cost>. This is a dimensionless metric.

`setportprio <bridge> <port> <prio>`

Sets the port <port>'s priority to <priority>. The priority value is an unsigned 8-bit quantity (a number between 0 and 255), and has no dimension. This metric is used in the designated port and root port selection algorithms.

`stp <bridge> <state>`

Controls this bridge instance's participation in the spanning tree protocol. If <state> is "on" or "yes" the STP will be turned on, otherwise it will be turned off. When turned off, the bridge will not send or receive BPDUs, and will thus not participate in the spanning tree protocol. If your bridge isn't the only bridge on the LAN, or if there are loops in the LAN's topology, DO NOT turn this option off. If you turn this option off, please know what you are doing.

OPTIONS

None.

EXAMPLES

- Display all the learned MAC addresses on br0
`brctl showmacs br0`
- Set the ageing timer value to be 400 seconds on br0
`brctl setageing br0 400`
- Turn off STP
`brctl stp br0 off`

CAT

NAME

cat - concatenates FILE(s) and prints them to standard output

SYNOPSIS

cat [FILE] ...

DESCRIPTION

Concatenates FILE(s) and prints them to standard output

COMMANDS

None.

OPTIONS

None.

EXAMPLES

- Display system memory information.
cat /proc/meminfo

DDNS

NAME

ddns - add, remove or show the dynamic DNS.

SYNOPSIS

```
ddns add <hostname> --username <username> --password <password>
      --interface <interface> --service <dyndns>
ddns remove <hostname>
ddns show
ddns --help
```

DESCRIPTION

The use of ddns command is to configure the dynamic DNS service provider account information. In CLI, only one operator, DynDNS.org, is supported at this point. This router will update the dynamic DNS service operator with the IP address associated with his DDNS host name whenever the IP address assigned to a specified WAN interface has been changed. Note that the user account for that dynamic DNS operator account must have been pre-established already.

OPTIONS

```
hostname
    the complete DNS host name pre-established in the DDNS service operator.
username
    the username of the dynamic DNS account.
password
    the password of the dynamic DNS account.
interface
    the WAN interface name that is associated with the dynamic IP address.
service
    the dynamic DNS service operator. Currently, it only support one service
    'dyndns' - service provider dyndns.org.
```

EXAMPLES

- Configure the dynamic DDNS host account associated with a provider and a WAN interface.


```
ddns add hostname.dyndns.org --username username --password password
      --interface waninterfacename --service dyndns.
```
- remove the dynamic DNS account configuration associated with a host name.


```
ddns remove hostname.dyndns.org.
```
- show the list of the dynamic DNS configurations in the router.


```
ddns show
```

DEFAULTGATEWAY

NAME

defaultgateway - configure or show the default gateway or default route

SYNOPSIS

```
defaultgateway config auto
defaultgateway config static [<ipaddress>] [<interface>]
defaultgateway show
defaultgateway --help
```

DESCRIPTION

The primary use of defaultgateway command is to set up a static default gateway or default route, or to retrieve the default gateway information automatically from remote ISPs through DHCP protocol for a MER interface or through PPP protocol for a PPPoA or PPPoE interface. A PPPoA or PPPoE interface will always retrieve remote gateway information automatically. This command will save configuration to the Permanent Storage.

If the default gateway is configured with static data, it will override any remote gateway address received automatically from some WAN interface and become effective immediately in the runtime system. Ipaddress is optional if the default route is en route a PPPoE, PPPoA or IPOA interface. If the default gateway is en route a MER interface, ipaddress must be configured and the interface parameter is optional. If there is only one IPOA WAN interface, you must configure static default gateway or default route since IPOA does not support DHCP.

If the default gateway is configured with the "auto" option, the system needs to be rebooted before it can take effect. If there are multiple WAN interfaces with DHCP or PPP enabled, multiple remote gateway addresses may be received and the first received will be chosen to be the default gateway.

OPTIONS

```
ipaddress
    the IP address of the default gateway in dotted decimal.
interface
    force the default gateway to be associated with the specified device, as
    the kernel will otherwise try to determine the device on its own by
    checking already existing routes and devices.
```

EXAMPLES

- Enable the system to retrieve the default gateway information automatically from the remote dhcp server when system starts. The system needs to be rebooted for modified configuration to take effect.


```
defaultgateway config auto
```
- Set up a static default gateway to 10.6.33.125. It should be effective right away and is saved to Permanent Storage on the flash memory.


```
defaultgateway config 10.6.33.125
```

DF

NAME

df - print the filesystem used space and available space

SYNOPSIS

df [OPTION]... [FILESYSTEM]...

DESCRIPTION

df displays the amount of disk space available on the file system of each filesystem name argument. If no file system name is given, the space available on all currently mounted filesystems is shown. Disk space is shown in 1 kb blocks by default.

COMMANDS

None.

OPTIONS

-h print sizes in human readable format (e.g., 1K 243M 2G)
-m print sizes in megabytes
-k print sizes in kilobytes (default)

EXAMPLES

- Display the space available on all the mounted file systems
df
- Display the space available on the flash root file system
df /dev/mtdblock0

DHCPSEVER

NAME

dhcpserver - allow a user to configure, or show the DHCP Server data

SYNOPSIS

```
dhcpserver config <start IP address> <end IP address> <leased time (hour)>
dhcpserver show
dhcpserver --help
```

DESCRIPTION

dhcpserver is used to configure, or show the DHCP server data. This utility can:

- configure the DHCP server on the primary LAN interface.
- show the DHCP server configuration data.
- display usage.

All information is displayed to stdout. A program or shell script that calls this utility can redirect stdout to a file and then parse the file in order to interpret the displayed output.

COMMANDS

```
config
    configure the DHCP server with the given data.
    Notice: the command saves the configuration data to the flash but does
    not take effect until the system is rebooted.
show
    show the DHCP server configuration data.
--help
    display usage.
```

OPTIONS

Options for the config command

```
dhcpserver config <start IP address> <end IP address> <leased time (hour)>.
```

<start IP address>

The IP address of the first address in the range. The value of range start must be less than or equal to the value of range end.

Valid values: any valid IP address.

Default value: 192.168.1.2.

<end IP address>

The IP address of the last address in the range. The value of range end must be greater than or equal to the value of range start.

Valid values: any valid IP address.

Default value: 192.168.1.254.

<leased time (hour)>

The lease period for which the server assigns an IP address to the client in case the client does not request for the specific lease period itself.

Valid values: 0 - 8760.

Default value: 24 hours (this equals a day).

Options for the show command

```
dhcpserver show
```

Options for the --help command

```
dhcpserver --help
```

EXAMPLES

- Configure DHCP server.
dhcpserver config 192.168.1.2 192.168.1.254 24

- Display DHCP server configuration data.
dhcpserver show

```
start 192.168.1.2
end 192.168.1.254
interface br0
option lease 86400
option min_lease 30
option subnet 255.255.255.0
option router 192.168.1.1
option dns 192.168.1.1
```

- Display usage.
Dhcpserver --help

```
Usage: dhcpserver config <start IP address> <end IP address>
      <leased time (hour)>
      dhcpserver show
      dhcpserver -help
```

DNSRELAY

NAME

dnsrelay - allow a user to configure or show the DNS relay data

SYNOPSIS

```
dnsrelay config auto
dnsrelay config static <primary DNS> [<secondary DNS>]
dnsrelay show
dnsrelay --help
```

DESCRIPTION

dnsrelay is used to configure, or show the DNS relay data. This utility can:

- configure the DNS relay with the given data.
- show the DNS relay configuration data.
- display usage.

All information is displayed to stdout. A program or shell script that calls this utility can redirect stdout to a file and then parse the file in order to interpret the displayed output.

COMMANDS

```
config
    configure the DNS relay with the given data.
    Notice: the command only saves the configuration data to the flash, and
    does not take effect until the system is rebooted.

show
    show the DNS relay configuration data.

--help
    display usage.
```

OPTIONS

Options for the config auto command

```
dnsrelay config auto
```

Options for the config static command

```
dnsrelay config static <primary DNS> [<secondary DNS>]
```

<primary DNS>

The IP address of the primary DNS server.

Valid values: any valid IP address.

[<secondary DNS>]

The IP address of the secondary DNS server. It is optional and can be omitted.

Valid values: any valid IP address.

Options for the show command

```
dnsrelay show
```

Options for the --help command

```
dnsrelay -help
```

EXAMPLES

- A auto DNS configuration.
dnsrelay config auto
- A static DNS configuration without secondary DNS.
dnsrelay config static 10.6.33.1
- A static DNS configuration with secondary DNS.
dnsrelay config static 10.6.33.1 10.6.33.2

- Display DNS relay configuration data.
dnsrelay show

Primary 10.6.33.1
Secondary 10.6.33.2

- Display usage.
dnsrelay --help

Usage: dnsrelay config auto

Usage: dnsrelay config static <primary DNS> [<secondary DNS>]
dnsrelay show
dnsrelay --help

DUMPCFG**NAME**

dumpcfg - display system;|s configuration

SYNOPSIS

dumpcfg

DESCRIPTION

dumpcfg displays the system;|s configuration which is in text XML format.

COMMANDS

None.

OPTIONS

None.

EXAMPLES

- Display the system's configuration.

Dumpcfg

```
<psitree>
<SecCfg>
<srvCtrlList ftp="lan" http="lan" icmp="lan" snmp="lan" ssh="lan" telnet="lan"
tftp="lan"/>
</SecCfg>
<AtmCfg>
<initCfg structureId="2" threadPriority="25" freeCellQSize="10" freePktQSize="200"
freePktQBufSize="1600" freePktQBufOffset="32" rxCellQSize="10" rxPktQSize="200"
txFifoPriority="64" aal5MaxSduLen="64" aal2MaxSduLen="0"/>
</AtmCfg>
<AtmCfgTd>
<td1 cat="UBR" PCR="0" SCR="0" MBS="0"/>
</AtmCfgTd>
<SystemInfo>
<sysLog state="enable" displayLevel="ERR" logLevel="DEBUG" option="local"
serverIP="0.0.0.0" serve rPort="514"/> <snmp state="disable" readCommunity="public"
writeCommunity="private" sysName="Broadcom" sysLocati on="unknown"
sysContact="unknown" trapIP="0.0.0.0"/> <sysUserName value="admin"/> <protocol
autoScan="enable" upnp="enable" macFilterPolicy="forward" siproxd="enable"/>
</SystemInfo>
<WirelessCfg>
<vars state="enabled" hide="0" ssid="Broadcom" country="ALL" authMode="open"
radiusServerIP="0.0.0.0" radiusServerPort="1812" radiusServerKey="" wep="disabled"
keyBit="128-bit" key64_1="" key64_2="" key64_3="" key64_4="" key64Index="1"
key128_1="" key128_2="" key128_3="" key128_4="" key128 Index="1" wpaRekey="0"
wpakey="" wpa="tkip" fltMacMode="disabled" apMode="ap" bridgeRestrict="d isabled"
wdsMAC_0="" wdsMAC_1="" wdsMAC_2="" wdsMAC_3="" apIsolation="off" band="b"
channel="11" rate="auto" multicastRate="auto" basicRate="default"
fragThreshold="2346" RTSThreshold="2347" DTIM="1" beacon="100" XPress="off"
gMode="auto" gProtection="auto" preamble="long"/>
</WirelessCfg>
<AtmCfgVcc>
<vccId1 vpi="0" vci="35" tdId="1" aalType="AAL5" adminStatus="up" encap="llc"
qos="disable"/>
</AtmCfgVcc>
<Lan>
<entry1 address="192.168.1.1" mask="255.255.255.0" dhcpServer="enable"
leasedTime="24" startAddr="192.168.1.2" endAddr="192.168.1.254"/>
</Lan>
<RouteCfg>
<ripGlobal state="disable" ripIfcTableSize="1"/>
<ripIfc tableSize="1"> <ripIfcEntry id="1" name="br0" state="disable" version="2"
operation="active"/>
</ripIfc>
</RouteCfg>
```

```
<ADSL/>
<DDNSCfg/>
<SNTPCfg/>
<ToDCfg/>
<ipsrv_0_35>
<dhcpconId1 state="disable" wanAddress="10.6.33.138" wanMask="255.255.255.0"/>
</ipsrv_0_35>
<wan_0_35>
<entry1 vccId="1" conId="1" name="ipoa_0_35" protocol="IPOA" encap="LLC"
firewall="disable" nat="disable" igmp="disable" service="enable"/>
</wan_0_35>
</psitree>
```

ECHO

NAME

echo - display a line of text or an environment variable's value

SYNOPSIS

echo [OPTION]... [STRING]...

DESCRIPTION

echo displays a line of text, or an environment variable's value. Notice that "ls" command is not supported in the CLI. Echo can be used to display files and subdirectories using wildcard `*|`.

COMMANDS

None.

OPTIONS

-n suppress trailing newline
-e interpret backslash-escaped characters (i.e., `\t=tab`)
-E disable interpretation of backslash-escaped characters

EXAMPLES

- Display a string
`echo "Hello, world"`
- Display the value of the environment variable `$TERM`
`echo $TERM`
- Display all files or subdirectories
`echo /etc/*`
`echo *`
`echo /var/*`

HELP

NAME

help - list all of available CLI commands that the AH4021 supports.

SYNOPSIS

Help | ?

DESCRIPTION

list all of available CLI commands that the AH4021 supports.

OPTIONS

None.

EXAMPLES

- An example is shown.

```
?  
help  
logout  
reboot  
adsl  
atm  
brctl  
cat  
df  
tftp  
echo  
ifconfig  
kill  
arp  
defaultgateway  
dhcpserver  
dns  
lan  
passwd  
ppp  
remoteaccess  
restoredefault  
route  
save  
swversion  
wan  
ping  
ps  
pwd  
sysinfo  
ddns  
sntp
```

IFCONFIG

NAME

ifconfig - configure a network interface

SYNOPSIS

```
ifconfig [interface]
ifconfig interface [atype] options | address ...
```

DESCRIPTION

Ifconfig is used to configure the kernel-resident network interfaces. It is used at boot time to set up interfaces as necessary. After that, it is usually only needed when debugging or when system tuning is needed.

If no arguments are given, ifconfig displays the status of the currently active interfaces. If a single interface argument is given, it displays the status of the given interface only; if a single -a argument is given, it displays the status of all interfaces, even those that are down. Otherwise, it configures an interface.

COMMANDS

None.

OPTIONS

```
interface
    The name of the interface. This is usually a driver name followed by a
    unit number, for example eth0 for the first Ethernet interface.
address
    The IP address to be assigned to this interface.
up
    This flag causes the interface to be activated. It is implicitly
    specified if an address is assigned to the interface.
down
    This flag causes the driver for this interface to be shut down.
[-]arp
    Enable or disable the use of the ARP protocol on this interface.
[-]promisc
    Enable or disable the promiscuous mode of the interface. If selected, all
    packets on the network will be received by the interface.
[-]allmulti
    Enable or disable all-multicast mode. If selected, all multicast packets
    on the network will be received by the interface.
metric N
    This parameter sets the interface metric.
mtu N
    This parameter sets the Maximum Transfer Unit (MTU) of an interface.
dstaddr addr
    Set the remote IP address for a point-to-point link (such as PPP). This
    keyword is now obsolete; use the pointpoint keyword instead.
netmask addr
    Set the IP network mask for this interface. This value defaults to the
    usual class A, B or C network mask (as derived from the interface
    IP address), but it can be set to any value.
irq addr
    Set the interrupt line used by this device. Not all devices can
    dynamically change their IRQ setting.
io_addr addr
    Set the start address in I/O space for this device.
mem_start addr
    Set the start address for shared memory used by this device. Only a few
    devices need this.
[-]broadcast [addr]
```

If the address argument is given, set the protocol broadcast address for this interface. Otherwise, set (or clear) the IFF_BROADCAST flag for the interface.

`[-]pointopoint [addr]`

This keyword enables the point-to-point mode of an interface, meaning that it is a direct link between two machines with nobody else listening on it. If the address argument is also given, set the protocol address of the other side of the link, just like the obsolete `dstaddr` keyword does. Otherwise, set or clear the IFF_POINTOPOINT flag for the interface.

`[-]trailers`

Set or clear the IFF_NOTRAILERS flag for the interface.

`[-]dynamic`

Set or clear the IFF_DYNAMIC flag for the interface.

`hw class address`

Set the hardware address of this interface, if the device driver supports this operation. The keyword must be followed by the name of the hardware class and the printable ASCII equivalent of the hardware address. Hardware classes currently supported include ether (Ethernet) only.

`multicast`

Set the multicast flag on the interface. This should not normally be needed as the drivers set the flag correctly themselves.

`outfill N`

This parameter sets the interface outfill timeout.

`keepalive N`

This parameter sets the interface keepalive timeout.

`txqueuelen length`

Set the length of the transmit queue of the device. It is useful to set this to small values for slower devices with a high latency (modem links, ISDN) to prevent fast bulk transfers from disturbing interactive traffic like telnet too much.

EXAMPLES

- Display all the active interfaces
ifconfig
- Set interface eth0's IP address to be 192.168.1.1, netmask to be 255.255.255.0
ifconfig eth0 192.168.1.1 netmask 255.255.255.0

KILL

NAME

kill - send a signal to the specified process(es)

SYNOPSIS

```
kill [ -signal ] pid ...  
kill -l [ signal ]
```

DESCRIPTION

kill sends the specified signal to the specified process or process group. If no signal is specified, the TERM signal is sent. The TERM signal will kill processes which do not catch this signal. For other processes, it may be necessary to use the KILL (9) signal, since this signal cannot be caught.

COMMANDS

None.

OPTIONS

pid... Specify the list of processes that kill should signal.
-signal given as a signal name or number.
-l List all signal names and numbers.

EXAMPLES

- Terminate the process with pid 120
kill 120
- Send KILL signal to the process with pid 120
kill -SIGKILL 120
- List all signal names and numbers
kill -l

LAN

NAME

lan - allow a user to configure the IP layer for the LAN interfaces

SYNOPSIS

```
lan config [--ipaddr <primary|secondary> <IP address> <subnet mask>]
           [--dhcpserver <enable|disable>]
lan delete -ipaddr <primary|secondary>
lan show [<primary|secondary>]
lan --help
```

DESCRIPTION

Lan is used to configure the IP layer data for the primary and secondary LAN interfaces. A LAN interface is a logic interface toward IP stack from the Bridge module. Both primary and secondary LAN interfaces share the same MAC address from the physical Ethernet port. This utility can:

- Configure the IP address and subnet mask for the primary LAN interface. It can be either a private or a public IP address.
- Configure the IP address and subnet mask for the secondary LAN interface. NAT is not supported on the secondary LAN interface. Only public IP address is allowed.
- Enable or disable the DHCP server on the primary LAN interface. DHCP server is not supported on the secondary LAN interface.
- Display configuration data for the primary and secondary LAN interfaces.
- Display usage.

All information is displayed to stdout. A program or shell script that calls this utility can redirect stdout to a file and then parse the file in order to interpret the displayed output.

COMMANDS

```
config      configure IP layer for the primary or secondary LAN interface.
delete      delete the primary or secondary LAN interface configuration.
show        show configuration data for the primary and secondary LAN interfaces.
--help      display usage.
```

OPTIONS

Options for the config command

```
lan config [--ipaddr <primary|secondary> <IP address> <subnet mask>]
           [--dhcpserver <enable|disable>]
```

```
--ipaddr <primary|secondary> <IP address> <subnet mask>
```

primary|secondary - specify which LAN interface will be configured.

Valid values: primary or secondary.

IP address - The IP address of the LAN interface.

Valid values: any valid IP address.

Default value: 192.168.1.1.

Subnet mask - The subnet mask of the LAN interface.

Valid values: 0.0.0.1 - 255.255.255.255.

Default value: 255.255.255.0

```
--dhcpserver <enable|disable>
```

enable|disable - specify DHCP server should be enabled or disabled. This option is only valid for the primary LAN interface.

Valid values: enable or disable.

Default value is enable for the primary LAN interface. Options for the delete command

```
lan delete --ipaddr <primary|secondary>
```

```
--ipaddr <primary|secondary>
```

```
primary|secondary - specify which LAN interface will be deleted.
Valid values: primary or secondary.
```

Options for the show command

```
lan show [<primary|secondary>]
```

```
primary|secondary - specify which LAN interface will be shown.
Valid values: primary or secondary.
If it is omitted, all LAN interfaces are displayed.
```

Options for the --help command

```
lan --help
```

EXAMPLES

- Configure a primary LAN interface.

```
lan config -ipaddr primary 192.168.1.1 255.255.255.0
```

- Remove a secondary LAN interface.

```
lan delete -ipaddr secondary
```

- Display all LAN interfaces.

```
lan show
```

```
br0 Link encap:Ethernet HWaddr 02:10:18:01:00:01
inet addr:192.168.1.1 Bcast:192.168.1.255 Mask:255.255.255.0
UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
RX packets:42083 errors:0 dropped:0 overruns:0 frame:0
TX packets:107786 errors:0 dropped:0 overruns:0 carrier:0
collisions:0 txqueuelen:0
RX bytes:7412118 (7.0 MiB) TX bytes:34445874 (32.8 MiB)
br0:0 Link encap:Ethernet HWaddr 02:10:18:01:00:01
UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
```

- Display usage.

```
lan -help
```

```
Usage: lan config [--ipaddr <primary|secondary> <IP address> <subnet mask>]
        [--dhcpserver <enable/disable>]
lan delete --ipaddr <primary|secondary>
lan show [<primary|secondary>]
lan -help
```

LOGOUT

NAME

logout - log out current user console

SYNOPSIS

logout

DESCRIPTION

logout is used to log out current user console. After logout command is executed, a bye bye message appears. Hit return to see a new Login prompt.

EXAMPLES

- Logout user admin.

Login: admin

Password:

> logout

Bye bye. Have a nice day!!!

Login:

PASSWD

NAME

passwd - allow a user to change password

SYNOPSIS

```
passwd <admin|support|user> <password>
```

DESCRIPTION

passwd is a CLI command used to change password for user account admin, support or user.

EXAMPLES

- Change password for user admin to broadcom.
> *passwd admin broadcom*

PING

NAME

ping - send ICMP echo requests to target host

SYNOPSIS

Ping [-c <count>] [-s <size>] host

DESCRIPTION

Ping sends out ICMP echo requests over the ICMP protocol to a host on the network. The default number of the ICMP echo request packets ping sends out is four. To continually send out packets without stop, use "-c 0" option.

OPTIONS

count

The number of ICMP echo request packets ping command will send out.

size

force the ping to send out ICMP echo request packets with this number of data bytes.

host

The name or ip address of the target host.

EXAMPLES

- Send eight ICMP echo requests to 192.168.0.5.
Ping -c 8 192.168.0.5

PPP

NAME

ppp - allow a user to bring up or bring down a ppp connection

SYNOPSIS

```
ppp config <port.vpi.vci> [<connection Id>] up|down
```

DESCRIPTION

ppp is used to control the ppp interfaces. Ppp command brings up the ppp connection with "up" option, and brings down the connection with "down" option. For ppp connection in on-demand mode, in addition to the "up" option, traffic to the ppp interface needs to be initiated to bring the connection up.

<port.vpi.vci>

Port number, VPI and VCI that identifies the VCC where the ppp connection is established.

<connection Id>

The number that identifies a existent WAN connection on a PVC. If connection Id is obmitted, the default is 1.

Valid values: 1 - 8.

Default value: 1

EXAMPLES

- Bring down the ppp connection on the 0.0.35 VCC.
ppp config 0.0.35 down

PS

NAME

ps - report process status

SYNOPSIS

ps

DESCRIPTION

ps gives a snapshot of the current processes. The output consists of six columns:

PID	The process ID
TTY	The terminal device the process attaches to, such as /dev/tty0
Uid	The user ID of the process owner
Size	The amount of virtual memory taken by the process (kilobytes)
State	The state of the process. (S-Sleeping, R-Running, W-Waiting)
Command	The command that launches the process

COMMANDS

None.

OPTIONS

None.

EXAMPLES

- Report process status
ps

PWD

NAME

pwd - print name of current working directory

SYNOPSIS

pwd

DESCRIPTION

pwd is a CLI command used to display name of current working directory.

EXAMPLES

- To see current working directory.
>pwd
/

REBOOT

NAME

reboot - reboot the system

SYNOPSIS

reboot

DESCRIPTION

Reboot the system.

COMMANDS

None.

OPTIONS

None.

EXAMPLES

- Reboot the system
reboot

REMOTEACCESS

NAME

remoteaccess - allow certain protocols to access the modem from the WAN side

SYNOPSIS

```
Usage: remoteaccess <enable|disable>
       remoteaccess show
       remoteaccess --help
```

DESCRIPTION

Remoteaccess sets security level to allow or disallow remote access into the route using telnet, http, snmp or ping from the WAN side. The options are enable, disable and show.

EXAMPLES

- Show current remote access mode.

```
>remoteaccess show
remote access is disabled
```
- Enable remote access.

```
> remoteaccess enable
```
- Disable remote access.

```
>remoteaccess disable
```

RESTOREDEFAULT

NAME

`restoredefault` - restore modem configuration to factory defaults

SYNOPSIS

`restoredefault`

DESCRIPTION

`restoredefault` is a CLI command used to erase all configurations made by user, and restore the modem back to factory default configuration. Once this command is executed, modem reboots automatically with default configuration.

EXAMPLES

- Restore configuration to factory defaults.
`>restoredefault`

ROUTE

NAME

route - show / manipulate the IP routing table

SYNOPSIS

```
route add <ipaddress> <subnetmask> [<gateway>] [<interface>]
route delete <ipaddress> <subnetmask>
route show
route --help
```

DESCRIPTION

route manipulates the IP routing table. Its primary use is to set up static routes to specific hosts or networks via an interface.

When the add or delete options are used, route modifies the routing tables. Show option displays the current contents of the routing tables.

Note default gateway route should use another ;\$defaultgateway;" command. If 0.0.0.0 is entered using route add command, it is treated the same as a static default gateway where a subnetmask must be entered.

COMMANDS

```
add          add a new route entry
delete       delete a route entry
show         show current content of routing table including static and dynamic
             route entries
```

OPTIONS

```
ipaddress    the destination network or host IP address in dotted decimal notation.
subnetmask   when adding a network route, the netmask must be specified. Target
             address must have zero matching with the zero portion in NM. Otherwise,
             command will fail and display message "netmask doesn't match route
             address"
gateway      route packets via a gateway. NOTE: The specified gateway must be
             reachable first. This usually means that you have to set up a static
             route to the gateway beforehand. If you specify the address of one of
             your local interfaces, it will be used to decide about the interface to
             which the packets should be routed to.
interface    force the route to be associated with the specified device, as the kernel
             will otherwise try to determine the device on its own by checking already
             existing routes and devices.
```

EXAMPLES

- add a route to the network 192.56.76.x via "br0" interface.
route add 192.56.76.0 255.255.255.0 br0
- add route to to gateway 10.6.33.129 for network 192.57.66.x.
route add 192.57.66.0 255.255.255.0 10.6.33.129

OUTPUT

The output of the kernel routing table is organized in the following columns

```
Destination  The destination network or destination host.
Gateway      The gateway address or * if none set.
```

Genmask

The netmask for the destination net; 255.255.255.255 for a host destination and 0.0.0.0 for the default route.

Flags

Possible flags include

U (route is up)

H (target is a host)

G (use gateway)

R (reinstate route for dynamic routing)

D (dynamically installed by daemon or redirect)

M (modified from routing daemon or redirect)

FILES

/proc/net/route

/proc/net/route_cache

SAVE

NAME

save - save current configuration to Permanent Storage on the flash memory

SYNOPSIS

save

DESCRIPTION

save is a CLI command used to save current configuration to flash.

EXAMPLES

- Save all current configuration to flash.
>save

Sntp

NAME

sntp - synchronize automatically router time with Internet time servers with a timezone.

SYNOPSIS

```
sntp -s server [ -s server2 ] -t "timezone"  
sntp disable  
sntp date  
sntp zones  
sntp --help
```

DESCRIPTION

sntp command synchronizes automatically the router's time with the specified internet timer servers.

OPTIONS

disable
 If Sntp is enable, disable it (require reboot).
date
 Show the current date and time of the router.
zones
 Show the list of the supported zones.

EXAMPLES

- To set up sntp server with "Pacific Time, Tijuana" zone
sntp -s time.nist.gov -t ;Pacific Time, Tijuana;
- To disable sntp (require reboot to be effective)
sntp disable
- To show the current date and time
sntp date
- To show a list of supported time zone
sntp zones
- To get a help
sntp --help

SWVERSION

NAME

swversion - display current running software version

SYNOPSIS

swversion show

DESCRIPTION

swversion is a CLI command used to view the current running software version.

EXAMPLES

- Display current software version.
> *swversion show*
AH4021.01.2.01.300L01.V28.mgcp.dspApp3341_fxo.LE9500A2pB018b.d15h

SYSINFO

NAME

sysinfo - display the general system information

SYNOPSIS

sysinfo

DESCRIPTION

sysinfo displays the number of processes in the system, system time, system uptime, the average system load in the past 1, 5 and 15 minutes, and the system memory consumption. The figures in the memory consumption table are in kkb unit.

COMMANDS

None.

OPTIONS

None.

EXAMPLES

- Display the system information
sysinfo

TFTP

NAME

tftp - tftp client to update software or retrieve and backup the configuration data.

SYNOPSIS

Usage: tftp [OPTION]... tftp_server_ip_address

DESCRIPTION

Tftp client is used for updating the software and configuration data from a remote tftp server as well as backup and retrieve the configuration to the remote tftp server.

COMMANDS

None.

OPTIONS

-g Get file. (Update image/configuration data)
-p Put file. (backup configuration data)
-f remote file name.
-t i for image and c for configuration data.

EXAMPLES

- To backup configuration data:
tftp -p -t c -f backupsetting.cfg 192.168.1.2
- To restore configuration data:
tftp -g -t c -f backupsetting.cfg 192.168.1.2
- To update software:
tftp -g -t i -f bcm96345_fs_kernel 192.168.1.2

Where the file name after "-f" should be the real file to be retrieved or backed up from tftp server.

VOICE

NAME

voice - manipulate voice-related parameters or start voice application

SYNOPSIS

```
voice --help
voice show
voice start
voice stop
voice set <parameter> <value>
```

COMMANDS

```
--help
    Displays the command syntax.

show
    Shows the voice-related parameters. For example, for MGCP application the
    following parameters are shown: call agent IP address, gateway name and
    interface used for sending the voice packets.

start
    Starts the voice application.

stop
    Stops the voice application.

set
    Configures the voice related parameters. These parameters are specific to
    type of voice protocol used in the voice application.
```

For MGCP, the following parameters can be set:

Parameter	Value
callagent	IP address of the call agent
gwname	Name of the MGCP gateway (this name is used in each MGCP message sent to the call agent)
interface	Interface name over which the MGCP and voice packets are sent (e.g. br0, nas25, etc.)
prefcodec	The codec that will be put in the first position of the codec list (e.g. auto, G711U, G729, etc.)
country	The country where the device is located
aaln	Endpoint name (e.g. aaln/1, where 'aaln/' is fixed)
caport	UDP port number used by call agent
clientport	UDP port number used by AH4021
txgain	Gain level for transmission
rxgain	Gain level for receiving
pstncode	PSTN access code
hbtimer	Time interval for sending Heartbeat packet
emergency	List of emergency numbers

For SIP, the following parameters can be set:

Parameter	Value
proxy	IP address and port for the SIP proxy server.
registrar	IP address and port for the SIP registrar server.
logserver	IP address and port for logging SIP messages.
extension	Phone extension (used only in combination with SIP proxy)
interface	Interface name over which the MGCP and voice packets are sent (e.g. br0, nas25, etc.)

NOTE: The values for the SIP proxy, registrar, and logserver should have the format ipaddress[:port]. See the examples below.

DESCRIPTION

Voice command enables manipulation of the voice-related parameters or starting the voice application.

EXAMPLES

- Show the voice-related parameters
`>voice show`

- Set the IP address for the MGCP callagent to 192.168.1.100
`>voice set callagent 192.168.1.100`

- Set the MGCP gateway name to [192.168.1.1]
`>voice set gwname [192.168.1.1]`

- Set the interface to nas25
`>voice set interface nas25`

- Set the SIP proxy IP address to 192.168.1.100, port number 12345
`>voice set proxy 192.168.1.100:12345`

- Set the SIP registrar IP address to 192.168.1.110
`>voice set registrar 192.168.1.110`

- Set the SIP log server IP address to 192.168.1.100, port number 12345
`>voice set logserver 192.168.1.100:12345`

- Set all the voice-related parameters to default values
`>voice set default`

- Start the voice application
`>voice start`

- Stop the voice application
`>voice stop`

WAN

NAME

wan - allow a user to configure the WAN interfaces for the AH4021

SYNOPSIS

```
wan config <port.vpi.vci> [<connection Id>]
    [--protocol <bridge|pppoe|pppoa|mer|ipoa>] [--encap <llc|vcmux>]
    [--state <enable|disable>] [--service <servicename>]
    [--firewall <enable|disable>] [--nat <enable|disable>]
    [--username <username> --password <password>]
    [--pppidletimeout <timeout>] [--pppipextension <disable|enable>]
    [--ipaddr <wanipaddress> <wansubnetmask>]
    [--dhcpclient <enable|disable>]

wan delete <port.vpi.vci>
wan show [<port.vpi.vci>]
wan --help <bridge|pppoe|pppoa|mer|ipoa>
```

DESCRIPTION

wan is used to configure the networking protocols for each WAN interface. Currently each WAN interface occupies one ATM PVC. It does not support multiple PPPoE sessions on one ATM PVC. Before using this command, the ATM PVC of which the WAN interface is based on, must be configured first by using the atm command. This command can:

- configure the protocol, encapsulation mode over ATM PVC, state, service name for each WAN interface.
- configure the username, password, idle timeout, and PPP IP extension for a PPPoE or a PPPoA interface.
- configure the IP address and subnet mask for a MER or a IPOA interface.
- enabling NAT or firewall for a MER or IPOA interface.
- enable or disable the DHCP client for a MER interface.
- delete the existed WAN interface (it will not delete the ATM PVC).
- show ATM PVC and WAN interface summary data and status.
- display usage for WAN interface.

All information is displayed to stdout. A program or shell script that calls this utility can redirect stdout to a file and then parse the file in order to interpret the displayed output. Note that special characters are supported in all options of character string type.

COMMANDS

```
config
    configure the WAN interface for the AH4021.
    Notice: the command only saves the configuration data to the flash, and
    does not take effect until the system is rebooted.

delete
    remove the existed WAN interface.
    Notice: the command only saves the configuration data to the flash, and
    does not take effect until the system is rebooted.

show
    show ATM PVC VPI/VCI, service category, WAN interface service name, WAN
    interface name, WAN protocol, WAN interface service state, WAN interface
    up/down status, and WAN IP address.

--help
    display usage for WAN interface.
```

OPTIONS

Options for the config command

```
wan config <port.vpi.vci>
    [--protocol <bridge|pppoe|pppoa|mer|ipoa>] [--encap <llc|vcmux>]
```

```

[--state <enable|disable>] [--service <servicename>]
[--firewall <enable|disable>] [--nat <enable|disable>]
[--username <username> --password <password>]
[--pppidletimeout <timeout>] [--pppipextension <disable|enable>]
[--ipaddr <wanipaddress> <wansubnetmask>]
[--dhcpcclient <enable|disable>]

<port.vpi.vci>
port: port number of the ATM VCC to add.
Valid values: 0.
vpi: VPI of the VCC to add.
Valid values: 0 - 255.
Default value: 0
vci: VCI of the VCC to add.
Valid values: 32 - 65535.
Default value: 35.
<connection Id>
The connection ID identifies a WAN connection on a PVC. To add a new WAN
connection, connection Id should be omitted. To edit an existent WAN
connection, connection Id can be specified to identify a specific WAN
connection. If omitted, it is defaulted to be 1.
Valid values: 1 - 8.
Default value: 1
--protocol <bridge|pppoe|pppoa|mer|ipoa>
The protocol of the WAN interface.
Valid values: bridge, pppoe, pppoa, mer, or ipoa.
Default value: bridge.
--encap <llc|vcmux>
The encapsulation type over the ATM PVC.
Valid values: llc or vc mux.
    llc -
        For mer, pppoe or bridge, it's RFC2684 bridged encapsulation
        For pppoa, it's RFC2364 LLC/NLPID encapsulation
    Vcmux - RFC2684 VC-MUX (null encapsulation).
Default value:
    llc for bridge, pppoe, mer, or ipoa.
    Vcmux for pppoa.
--state <enable|disable>
The service state of the WAN interface.
Valid values: enable or disable.
Default value: enable.
--service <servicename>
The service name of the WAN interface.
Valid values: strings of 32 characters.
Default value: <protocol>_<vpi>_<vci>.
--firewall <enable|disable>
The firewall state of the MER or IPOA interface.
Notice that firewall is always enabled on a PPPoE or a PPPoA interface.

Valid values: enable or disable.
Default value: enable.
--nat <enable|disable>
The NAT state of the MER or IPOA interface.
Notice that NAT is always enabled on a PPPoE or a PPPoA interface.
Valid values: enable or disable.
Default value: enable.
--username <username>
The login name of the PPPoE or PPPoA interface.
This option is only applied to a PPPoE or PPPoA interface.
The --password option is also needed when this option is used.
Valid values: string of 32 characters.
--password <password>
The password of the PPPoE or PPPoA interface.

```

- This option is only applied to a PPPoE or PPPoA interface.
 The --username option is also needed when this option is used.
 Valid values: string of 256 characters.
- pppidletimeout <timeout>
 The PPP timeout of a PPPoE or PPPoA interface. This option is only applied to a PPPoE or PPPoA interface.
 Valid values: 0 - 1090 (minutes).
 0: PPP connection is always-on.
 Greater than 0: WAN traffic will be monitored and PPP connection will be torn down when there is no user data activity over the WAN interface for more than this idle time period.
 Default value: 30 minutes.
- pppipextension <disable|enable>
 The PPP IP extension mode of a PPPoE or PPPoA interface.
 This option is only applied to a PPPoE or PPPoA interface.
 Valid values: disable or enable.
 Default value: disable.
- ipaddr <wanipaddress> <wansubnetmask>
 The WAN IP address and WAN subnet mask of a MER or IPOA interface.
 This option should only be used for a MER or IPOA interface. PPPoE and PPPoA interface always receives the IP address, submask and DNS addresses automatically from the ISP through the PPP protocol. If this option is used and the dhcpclient value is "enable", DHCP client will be disabled on this interface. In general principle, static configuration overwrites dynamically assigned data.
 <wanipaddress> - the WAN IP address.
 Valid values: any valid IP address.
 <wansubnetmask> - the WAN subnet mask.
 Valid values: 0.0.0.1 - 255.255.255.255.
- dhcpclient <enable|disable>
 The DHCP client state of the MER interface. This option is only valid to a MER interface. DHCP client is not supported over any other type of WAN interface.
 Valid values: enable or disable.
 Default value: enable.

Options for the delete command

wan delete <port.vpi.vci> [<connection Id>]

<port.vpi.vci>

port: port number of the VCC to add.

Valid values: 0.

vpi: VPI of the VCC to add.

Valid values: 0 - 255.

Default value: 0

vci: VCI of the VCC to add.

Valid values: 32 - 65535.

Default value: 35.

<connection Id>

The number that identifies the existed WAN connection. If the connection Id is omitted, then its value is 1.

Valid values: 1 - 8.

Default value: 1

Options for the show command

wan show [<port.vpi.vci>]

<port.vpi.vci>

port: port number of the VCC to add.

Valid values: 0.

vpi: VPI of the VCC to add.

Valid values: 0 - 255.

Default value: 0

vci: VCI of the VCC to add.
 Valid values: 32 - 65535.
 Default value: 35
 If <port.vpi.vci> is omitted then it will display summary state of all existing WAN interfaces. Notice, configuration needs to be saved to the Permanent Storage first and then become effective after reboot. The wan show command shows the WAN interfaces after reboot, the second stage.

Options for the --help command

wan -help [<bridge|pppoe|pppoa|mer|ipoa>]

<bridge|pppoe|pppoa|mer|ipoa>

Display only valid options for the specified protocol.
 If it is omitted then the help for all protocols is displayed.

EXAMPLES

- Configure a PPPoE interface
 wan config 0.0.35 --protocol pppoe --username username --password password --encap llc
- Configure a PPPoA interface
 wan config 0.0.36 --protocol pppoa --username username --password password --encap vcmux
- Configure a MER configuration using DHCP client
 wan config 0.0.37 --protocol mer --encap llc
- Configure a MER configuration using static WAN address
 wan config 0.0.37 --protocol mer --encap llc --ipaddr 10.6.33.163 255.255.255.0
- Configure a IPoA configuration without fireware, without NAT
 wan config 0.0.40 --protocol ipoa --encap llc --firewall disable --nat disable --ipaddr 10.6.33.227 255.255.255.0
- Configure a bridge configuration
 wan config 0.2.35
- Remove a WAN interface
 wan delete 0.2.35
- Display all WAN interfaces
 wan show

```

=====
VCC    Catego. Service      Intf.   Proto.  State   Status  IP
      Name          Name
=====
0.0.35 UBR      pppoe_0_35  ppp33   PPPoE   Enable  Up      10.6.33.143
0.0.36 UBR      pppoa_0_36  ppp42   PPPoA   Enable  Up      10.6.33.152
0.0.37 UBR      mer_0_37    nas27   MER     Enable  Up      10.6.33.193
0.0.40 UBR      ipoa_0_40   atm52   IPoA    Enable  Up      10.6.33.227
=====
    
```

- Display usage for all protocols
 wan -help
 Usage: wan config <port.vpi.vci>
 [--protocol <bridge|pppoe|pppoa|mer|ipoa>] [--encap <llc|vcmux>]
 [--state <enable|disable>] [--service <servicename>]
 [--firewall <enable|disable>] [--nat <enable|disable>]
 [--username <username> --password <password>] [--pppidletimeout <timeout>]
 [--pppipextension <disable|enable>] [--ipaddr <wanipaddress> <wansubnetmask>
 [--dhcpclient <enable|disable>]


```
wan delete <port.vpi.vci>  
wan show [<port.vpi.vci>]  
wan --help <bridge/pppoe/pppoa/mer/ipoa>
```

- Display usage for bridge

```
wan -help bridge
```

```
Usage: wan config <port.vpi.vci>  
      [--protocol <bridge/pppoe/pppoa/mer/ipoa>] [--encap <llc/vcmux>]  
      [--state <enable/disable>] [--service <servicename>]  
wan delete <port.vpi.vci>  
wan show [<port.vpi.vci>]  
wan --help <bridge/pppoe/pppoa/mer/ipoa>
```

WLCTL**NAME**

wlctl - allow a user to configure the Wireless interfaces for the AH4021

SYNOPSIS

```
wlctl [-a|i <adapter>] [-hu] <command> [arguments]
```

DESCRIPTION

wlctl is used to configure the parameters of WiFi interface including SSID, rate, channel, security settings, etc.

OPTIONS

```
Ver
    get version information

cmds
    generate a short list of available commands

up
    reinitialize and mark adapter up (operational)

down
    reset and mark adapter down (disabled)

out
    mark adapter down but do not reset hardware(disabled)
    On dualband cards, cards must be bandlocked before use.

Clk
    set board clock state. return error for set_clk attempt if the driver is
    not down
    0: clock off
    1: clock on

restart
    Restart driver. Driver must already be down.

Reboot
    Reboot platform

Ucflags
    Get/Set ucode flags

Radio
    Set the radio on or off.
    "on" or "off"

dump
    print driver software state and chip registers to stdout

srdump
    print contents of SPROM to stdout

nvdump
    print nvram variables to stdout

lodump
    print measlo table to stdout

nvset
    set an nvram variable
    name=value (no spaces around '=')

nvget
    get the value of an nvram variable

revinfo
    get hardware revision information

msglevel
    set driver console debugging message bitvector
    type 'wlctl msglevel ?' for values

PM
    set driver power management mode:
    0: CAM (constantly awake)
    1: PS (power-save)
    2: FAST PS mode

wake
```

```

    set driver power-save mode sleep state:
    0: core-managed
    1: awake
promisc
    set promiscuous mode ethernet address reception
    0 - disable
    1 - enable
monitor
    set monitor mode
    0 - disable
    1 - enable active monitor mode (interface still operates)
frag
    Set the fragmentation threshold. (integer [256, 2346])
rts
    Set the RTS threshold. (integer [0, 2347])
cwmin
    Set the cwmin. (integer [1, 255])
cwmax
    Set the cwmax. (integer [256, 2047])
srl
    Set the short retry limit. (integer [1, 255])
lrl
    Set the long retry limit. (integer [1, 255])
rate
    force a fixed rate:
    valid values for 802.11a are (6, 9, 12, 18, 24, 36, 48, 54)
    valid values for 802.11b are (1, 2, 5.5, 11)
    valid values for 802.11g are (1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48, 54)

    -1 (default) means automatically determine the best rate
mrate
    force a fixed multicast rate:
    valid values for 802.11a are (6, 9, 12, 18, 24, 36, 48, 54)
    valid values for 802.11b are (1, 2, 5.5, 11)
    valid values for 802.11g are (1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48, 54)

    -1 (default) means automatically determine the best rate
a_rate
    force a fixed rate for the A PHY:
    valid values for 802.11a are (6, 9, 12, 18, 24, 36, 48, 54)
    -1 (default) means automatically determine the best rate
a_mrate
    force a fixed multicast rate for the A PHY:
    valid values for 802.11a are (6, 9, 12, 18, 24, 36, 48, 54)
    -1 (default) means automatically determine the best rate
bg_rate
    force a fixed rate for the B/G PHY:
    valid values for 802.11b are (1, 2, 5.5, 11)
    valid values for 802.11g are (1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48, 54)

    -1 (default) means automatically determine the best rate
bg_mrate
    force a fixed multicast rate for the B/G PHY:
    valid values for 802.11b are (1, 2, 5.5, 11)
    valid values for 802.11g are (1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48, 54)

    -1 (default) means automatically determine the best rate
infra
    Set Infrastructure mode: 0 (IBSS) or 1 (Infra BSS)
ap
    Set AP mode: 0 (STA) or 1 (AP)
bssid
    Get the BSSID value, error if STA and not associated

```

channe
 Set the channel:
 valid channels for 802.11b/g (2.4GHz band) are 1 through 14
 valid channels for 802.11a (5 GHz band) are:
 36, 40, 44, 48, 52, 56, 60, 64,
 100, 104, 108, 112, 116,120, 124, 128, 132, 136, 140,
 149, 153, 157, 161,
 184, 188, 192, 196, 200, 204, 208, 212, 216

tssi
 Get the tssi value from radio

txpwr
 Set tx power in milliwatts. Range [1, 84]. (Deprecated: Use txpwrl instead)

txpwrl
 Set tx power in in various units. Choose one of (default: dbm):
 -d dbm units
 -q quarter dbm units
 -m milliwatt units
 Can be combined with:
 -o turn on override to disable regulatory and other limitations
 Use wl txpwr -1 to restore defaults

txpathpwr
 Turn the tx path power on or off on 2050 radios

txpwrlimit
 Return current tx power limit

powerindex
 Set the transmit power for A band(0-63).
 -1 - default value

atten
 Set the transmit attenuation for B band. Args: bb radio txctl1.
 auto to revert to automatic control

phyreg
 Get/Set a phy register.

radioreg
 Get/Set a radio register.

shmem
 Get/Set a shared memory location.

macreg
 Get/Set any mac registers(include IHR and SB)
 macreg offset size[2,4] [value]

antdiv
 Set antenna diversity for rx
 0 - force use of antenna 0
 1 - force use of antenna 1
 3 - automatic selection of antenna diversity

txant
 Set the transmit antenna
 0 - force use of antenna 0
 1 - force use of antenna 1
 3 - use the RX antenna selection that was in force during
 the most recently received good PLCP header

ratedump
 Print driver rate selection tunables and per-scb state to stdout
 based on remote station mac address[xx:xx:xx:xx:xx:xx]

plcphdr Set the plcp header.
 "long" or "auto" or "debug"

phytype
 Get phy type

scbdump
 print driver scb state to stdout

rateparam
 set driver rate selection tunables
 arg 1: tunable id

```

    arg 2: tunable value
wepstatus
    Set or Get WEP status
    wepstatus [on|off]
primary_key
    Set or get index of primary key
addwep
    Set an encryption key. The key must be 5, 13 or 16 bytes long, or
    10, 26, 32, or 64 hex digits long. The encryption algorithm is
    automatically selected based on the key size. keytype is accepted
    only when key length is 16 bytes/32 hex digits and specifies
    whether AES-OCB or AES-CCM encryption is used. Default is ccm.
    addwep <keyindex> <keydata> [ocb | ccm] [notx] [xx:xx:xx:xx:xx:xx]
rmwep
    Remove the encryption key at the specified key index.
wep
    Set WEP options.
    wlctl wep [options]
    [on|enable|1] enable WEP
    [off|disable|0] disable WEP
    [sw|software] perform WEP in software
    [hw|hardware] perform WEP in hardware
tkip
    Set TKIP options.
    wlctl tkip [options]
    [on|enable|1] enable TKIP
    [off|disable|0] disable TKIP
    [sw|software] perform TKIP in software
    [hw|hardware] perform TKIP in hardware
aes
    Set AES options.
    wlctl aes [options]
    [on|enable|1] enable AES
    [off|disable|0] disable AES
    [sw|software] perform AES in software
    [hw|hardware] perform AES in hardware
keys
    Prints a list of the current WEP keys
tsc
    Print Tx Sequence Counter for key at specified key index.
wsec_test
    Generate wsec errors
    wsec_test <test_type> <keyindex|xx:xx:xx:xx:xx:xx>
    type 'wlctl wsec_test ?' for test_types
tkip_countermeasures
    Enable or disable TKIP countermeasures (TKIP-enabled AP only)
    0 - disable
    1 - enable
wsec_restrict
    Drop unencrypted packets if WSEC is enabled
    0 - disable
    1 - enable
eap
    restrict traffic to 802.1X packets until 802.1X authorization succeeds
    0 - disable
    1 - enable
authorize
    restrict traffic to 802.1X packets until 802.1X authorization succeeds
deauthorize
    do not restrict traffic to 802.1X packets until 802.1X authorization
    succeeds
deauthenticate
deauthenticate a STA from the AP with optional reason code (AP ONLY)

```

```

wsec
    wireless security bit vector
    1 - WEP enabled
    2 - TKIP enabled
    4 - AES enabled
    8 - WSEC in software
wpa_auth
    Bitvector of WPA authorization modes:
    1      WPA NONE
    2      WPA-802.1X/WPA-Professional
    4      WPA-PSK/WPA-Personal
    64     WPA2-802.1X/WPA2-Professional
    128    WPA2-PSK/WPA2-Personal
    0      disable WPA
set_pmk
    Set passphrase for PMK in driver-resident supplicant.
scan
    Initiate a scan.
    Default an active scan across all channels for any SSID.
    Optional arg: SSID, the SSID to scan.
    Options:
    -s S, --ssid=S          SSID to scan
    -t ST, --scan_type=ST  [active|passive] scan type
    --bss_type=BT          [bss/infra|ibss/adhoc] bss type to scan
    -b MAC, --bssid=MAC    particular BSSID MAC address to scan,
    xx:xx:xx:xx:xx:xx
    -n N, --nprobes=N      number of probes per scanned channel
    -a N, --active=N       dwell time per channel for active scanning
    -p N, --passive=N     dwell time per channel for passive scanning
    -h N, --home=N        dwell time for the home channel between channel
    scans
    -c L, --channels=L     comma or space separated list of channels to scan
passive
    Puts scan engine into passive mode
regulatory
    Get/Set regulatory domain mode (802.11d). Driver must be down.
spect
    Get/Set 802.11h Spectrum Management mode.
    0 - Off
    1 - Loose interpretation of spec - may join non-11h APs
    2 - Strict interpretation of spec - may not join non-11h APs
scanresults
    Return results from last scan.
assoc
    Print information about current network association.
    (also known as "status")
status
    Print information about current network association.
    (also known as "assoc")
disassoc
    Disassociate from the current BSS/IBSS.
chanlist
    Return valid channels for the current settings.
channels
    Return valid channels for the current settings.
channels_in_country
    Return valid channels for the country specified.
    Arg 1 is the country abbreviation
    Arg 2 is the band(a or b)
curpower
    Return current tx power settings
scansuppress
    Suppress all scans for testing.

```

```

    0 - allow scans
    1 - suppress scans
evm
    Start an EVM test on the given channel, or stop EVM test.
    Arg 1 is channel number 1-14, or "off" or 0 to stop the test.
    Arg 2 is optional rate (1, 2, 5.5 or 11)
rateset
    Returns or sets the supported and basic rateset, (b) indicates basic
    With no args, returns the rateset. Args are
    rateset "default" | "all" | <arbitrary rateset>
        default - driver defaults
        all - all rates are basic rates
        arbitrary rateset - list of rates
    List of rates are in Mbps and each rate is optionally followed by "(b)"
    or "b" for a Basic rate. Example: 1(b) 2b 5.5 11
    At least one rate must be Basic for a legal rateset.
roam_trigger
    Set the roam trigger RSSI threshold. (integer)
roam_delta
    Set the roam candidate qualification delta. (integer)
roam_scan_period
    Set the roam candidate qualification delta. (integer)
suprates
    Returns or sets the llg override for the supported rateset
    With no args, returns the rateset. Args are a list of rates,
    or 0 or -1 to specify an empty rateset to clear the override.
    List of rates are in Mbps, example: 1 2 5.5 11
scan_channel_time
    Get/Set scan channel time
scan_unassoc_time
    Get/Set unassociated scan channel dwell time
scan_home_time
    Get/Set scan home channel dwell time
scan_passive_time
    Get/Set passive scan channel dwell time
scan_nprobes
    Get/Set scan parameter for number of probes to use per channel scanned
prb_resp_timeout
    Get/Set probe response timeout
channel_qa
    Get last channel quality measurment
channel_qa_start
    Start a channel quality measurment
country
    Select Country code for use with 802.11d
    Use either long name or abbreviation from ISO 3166.
    Use 'wlctl country list [band(a or b)]' for the list of supported
    countries
locale
    OBSOLETE: use "wlctl country"
    Select the country:
    Worldwide
    Thailand
    Israel
    Jordan
    China
    Japan
    USA/Canada/ANZ
    Europe
    USAlow
    JapanHigh
    All
join

```

```

Join a specified network SSID.
Join syntax is: join <ssid> [key xxxxxx] [imode bss|ibss]
[amode open|shared|wpa|wpapsk|wpanone]
ssid
Set or get the current SSID.
Setting will initiate an association attempt if in infrastructure mode,
or join/creation of an IBSS if in IBSS mode,
or creation of a BSS if in AP mode.
mac
Set or get the list of source MAC address matches.
wlctl mac xx:xx:xx:xx:xx:xx [xx:xx:xx:xx:xx:xx ...]
To Clear the list: wl mac none
macmode
Set the mode of the MAC list.
0 - Disable MAC address matching.
1 - Deny association to stations on the MAC list.
2 - Allow association to stations on the MAC list.
wds
Set or get the list of WDS member MAC addresses.
Set using a space separated list of MAC addresses.
wlctl wds xx:xx:xx:xx:xx:xx [xx:xx:xx:xx:xx:xx ...]
lazywds
Set or get "lazy" WDS mode (dynamically grant WDS membership to anyone).
noise
Get noise (moving average) right after tx in dBm
fqacurcy
Manufacturing test: set frequency accuracy mode.
freqacurcy syntax is: fqacurcy <channel>
Arg is channel number 1-14, or 0 to stop the test.
crsuprs
Manufacturing test: set carrier suppression mode.
carriersuprs syntax is: crsuprs <channel>
Arg is channel number 1-14, or 0 to stop the test.
int
Interrupt Test - remember to precede by 'wlctl down' and follow by 'wlctl
up'
lbt
Loopback Test - remember to precede by 'wlctl down' and follow by 'wlctl
up'
band
Returns or sets the current band
auto - auto switch between available bands (default)
a - force use of 802.11a band
b - force use of 802.11b band
bands
Return the list of available 802.11 bands
phylst
Return the list of available phytypes
shortslot
Get current 11g Short Slot Timing mode. (0=long, 1=short)
shortslot_override
Get/Set 11g Short Slot Timing mode override. (-1=auto, 0=long, 1=short)
shortslot_restrict
Get/Set AP Restriction on associations for 11g Short Slot Timing capable
STAs.
0 - Do not restrict association based on ShortSlot capability
1 - Restrict association to STAs with ShortSlot capability
ignore_bcns
AP only (G mode): Check for beacons without NONERP element (0=Examine
beacons, 1=Ignore beacons)
pktcnt
Get the summary of good and bad packets.
upgrade

```



```

    Upgrade the firmware on an embedded device
gmode
    Set the 54g Mode (LegacyB|Auto||GOnly|BDeferred|Performance|LRS)
gmode_protection
    Get G protection mode. (0=disabled, 1=enabled)
gmode_protection_control
    Get/Set 11g protection mode control alg. (0=always off, 1=monitor local
    association, 2=monitor overlapping BSS)
gmode_protection_cts
    Get/Set 11g protection type to CTS (0=disable, 1=enable)
gmode_protection_override
    Get/Set 11g protection mode override. (-1=auto, 0=disable, 1=enable)
legacy_erp
    Get/Set 11g legacy ERP inclusion (0=disable, 1=enable)
scb_timeout
    AP only: inactivity timeout value for authenticated stas
assoclist
    AP only: Get the list of associated MAC addresses.
rssi
    Get the current RSSI val, for an AP you must specify the mac addr of the
    STA
isup
    Get driver operational state (0=down, 1=up)
fasttimer
    Get/Set High frequency watchdog timeout (tx_power) [15 sec]
slowtimer
    Get/Set Low frequency watchdog timeout (nrssislope) [60 sec]
glacialtimer
    Get/Set Very Low frequency watchdog timeout (measurelo) [120 sec]
radar
    Enable/Disable radar
rssidump
    Dump rssi values from aci scans
interference
    Get/Set interference mitigation mode. Choices are:
    0 = none
    1 = non wlan
    2 = wlan manual
    3 = wlan automatic
aciargs
    Get/Set various aci tuning parameters. Choices are:
    enter: CRS glitch trigger level to start detecting ACI
    exit: CRS glitch trigger level to exit ACI mode
    glitch: Seconds interval between ACI scans when glitchcount is
    continuously high
    spin: Num microseconds to delay between rssi samples
    Usage: wlctl aciargs [enter x][exit x][spin x][glitch x]
frameburst
    Disable/Enable frameburst mode
pwr_percent
    Get/Set power output percentage
wet
    Get/Set wireless ethernet bridging mode
bi
    Get/Set the beacon period (bi=beacon interval)
dtim
    Get/Set DTIM
wds_remote_mac
    Get WDS link remote endpoint's MAC address
wds_wpa_role_old
    Get WDS link local endpoint's WPA role (old)
wds_wpa_role
    Get/Set WDS link local endpoint's WPA role

```

```

authe_sta_list
    Get authenticated sta mac address list
autho_sta_list
    Get authorized sta mac address list
measure_req
    Send an 802.11h measurement request.
    Usage: wlctl measure_req <type> <target MAC addr>
    Measurement types are: TPC, Basic, CCA, RPI
    Target MAC addr format is xx:xx:xx:xx:xx:xx
quiet
    Send an 802.11h quiet command.
    Usage: wlctl quiet <TBTTs until start>, <duration (in TUs)>, <offset (in
    TUs)>
csa
    Send an 802.11h channel switch announcement
    Usage wlctl csa <mode> <when (in TBTTs)> <channel>
constraint
    Send an 802.11h Power Constraint IE
    Usage: wlctl constraint 1-255 db
rm_req
    Request a radio measurement of type basic, cca, or rpi
    Specify a series of measurement types each followed by options.
    example: wl rm_req cca -c 1 -d 50 cca -c 6 cca -c 11
    Options:
    -t n numeric token id for measurement set or measurement
    -c n channel
    -d n duration in TUs (1024 us)
    -p parallel flag, measurement starts at the same time as previous
    Each measurement specified uses the same channel and duration as the
    previous unless a new channel or duration is specified.
rm_rep
    Get current radio measurement report
wme
    Set WME (Wireless Multimedia Extensions) mode (0=off, 1=on)
wme-ac
    Usage: wlctl wme-ac sta/ap [be, bk, vi, vo] [ecwmax, ecwmin, txop, aifsn,
    acm] value
sta_info
    wl sta_info <xx:xx:xx:xx:xx:xx>
cap
    driver capabilities
malloc_dump
    debug malloc info
chan_info
    channel info
add_ie
    Add a vendor proprietary IE to 802.11 management packets
    Usage: wlctl add_ie <pktflag> length OUI hexdata
    <pktflag>: Bit 0 - Beacons
    Bit 1 - Probe Rsp
    Bit 2 - Assoc/Reassoc Rsp
    Bit 3 - Auth Rsp
    Example: wlctl add_ie 3 10 00:90:4C 0101050c121a03
    to add this IE to beacons and probe responses
del_ie
    Delete a vendor proprietary IE from 802.11 management packets
    Usage: wlctl del_ie <pktflag> length OUI hexdata
    <pktflag>: Bit 0 - Beacons
    Bit 1 - Probe Rsp
    Bit 2 - Assoc/Reassoc Rsp
    Bit 3 - Auth Rsp
    Example: wlctl del_ie 3 10 00:90:4C 0101050c121a03
list_ie

```

```
    Dump the list of vendor proprietary IEs
rand
    Get a 2-byte Random Number from the MAC's PRNG
    Usage: wlctl rand
corerev
    Get current core revision
autochannel
    auto channel selection
close
    hides the network from active scans, 0 or 1.
    0 is open, 1 is hide
beacon
    Set the beacon interval:
    valid beacon interval are 1-65535
auth
    Sets the shared key authentication method
    0 is optional, 1 is required
ssid
    Set the SSID ID value
    <name|ssid>
```

EXAMPLES

- Display WEP key information.
wlctl keys

The current WEP keys:

- 1.
- 2.
- 3.
- 4.